


VeGA WBC 520 2018

No.	ID Zboží	Název
1	50WBC520V001	BYLON HEAD
2	50WBC520V002	DOWN PRESSING COVER
3	50WBC520V003	M5x14 SCREW
4	50WBC520V004	DABRIS PROTECTOR
5	50WBC520V005	GEAR ASSY (26)
6	50WBC520V006	M5x12 SREW
7	50WBC520V007	M5x25 SCREW
8	50WBC520V008	M5x20 SCREW
9	50WBC520V009	KNIFE 40x20x36
10	50WBC520V010	LOCKNUT M5
11	50WBC520V011	TRANSMISSION SHAFT (8x385)
12	50WBC520V012	SHAFT SLEEVES (8x22x20)
13	50WBC520V013	SHAFT TUBE (26x360)
14	50WBC520V014	M6x35 SCREW
15	50WBC520V015	
16	50WBC520V016	LOCKNUT 12
17	50WBC520V017	WASHER 12 (13x32x2)
18	50WBC520V018	BEARING 6001-2Z (12x28x8)
19	50WBC520V019	WHEELS (310)
20	50WBC520V020	BEARING RING 12
21	50WBC520V021	BODY FRAME
22	50WBC520V022	M6x30 SCREW
23	50WBC520V023	HOUSING ASSY (26)
24	50WBC520V024	1E43F ENGINE
25	50WBC520V025	PIPE 5.2x8x10
26	50WBC520V026	DUSTPROOF COVER
27	50WBC520V027	OIL CONTROL ASSY
28	50WBC520V028	LOCKNUT M6
29	50WBC520V029	M6x40 SCREW
30	50WBC520V030	KNOB M 8x40
31	50WBC520V031	LOWER CONNECTING POLE
32	50WBC520V032	MIDDLE CONNNECTING POLE
33	50WBC520V033	UPPER CONNNECTING POLE
34	50WBC520V034	LEFT HANDLE COVER
35	50WBC520V035	PROTECTOR PRESSING COVER
36	50WBC520V036	NUT



N76	BRANKET, TANK	1	N66	STARTER KNOB	1
N75	TANK	1	N65	STARTER ROPE	1
N74	FUEL FILTER	1	N64	STARTER	1
N73	PIPE SET	1	N63	NUT	2
N72	FUEL PIPE	3	N62	SPRING	1
N71	CLIP	1	N61	REEL	1
N70	EQUILIBRATOR	1	N60	TORSION SPRING	1
N69	CAP	1	N59	RATCHET	1
N68	FUEL TANK ASS'Y		N58	SCREW	1
N67	COLLAR	1	N57	STARTER ASS'Y	

N56	NUT M8	1	N50	WOODRUFF KEY	1
N55	PULLET	1	N49	BEARING 6202	2
N54	OIL SEAL 12×22×7	1	N48	LEFT CRANKCASE	1
N53	RIGHT CRANKCASE	1	N47	BOLT M5×35	4
N52	GASKET, CRANKCASE	1	N46	OIL SEAL 10×30×7	1
N51	CRANKSHAFT	1	N45	PIN Ø5×10	4

N44	BRAND BADGE	1
N43	KNOB	1
N42	COVER, FILTER	1
N41	ELEMENT	1
N40	BOLT M5×55	2
N39	AIR FILTER SET	1

N38	CARBURATOR	1
N37	GASKET, CARBURATOR	1
N36	INLET PIPE	1
N35	GASKET, INLET PIPE	1
N34	NEEDLE BEARING	1
N33	SNAP RING, PISTON PIN	2
N32	PISTON PIN	1
N31	PISTON	1
N30	PISTON RING	2
N29	GASKET, CYLINDER	1
N28	CYLINDER	1
N27	GASKET, MUFFLER	1
N26	BOLT M4×14	1
N25	MUFFLER	1
N24	BOLT M5×10	1
N23	HEAT INSULATION, MUFFLER	1
N22	BOLT M6×55	2
N21	BRAND BADGE	1
N20	ST4×8	2
N19	TOP COVER	1
N18	COVER, CYLINDER	1
N17	BOLT M4×12	2
N16	BOLT M5×10	1
N15	BOLT	1
N14	BOLT M5×20	4
N13	SPARK PLUG	1
N12	CAP, SPARK PLUG	1
N11	IGNITION COIL	1
N10	BOLT M5×20	10
N9	FLYWHEEL	1
N8	FLANGE NUT M8	1
N7	WASHER	2
N6	CLUTCH	1
N5	WASHER	2
N4	SCREW, CLUTCH	2
N3	SIDE COVER	1
N2	BOLT M5×20	1
N1	BOLT M5×25	3
No.	Description	Qty

No.	ID Zboží	Název
N1	50BC525M01	Bolt M5x25
N2	50BC525M02	Bolt M5x20
N3	50BC525M03	Side cover
N4	50BC525M04	Screw, Clutch
N5	50BC525M05	Washer
N6	50BC525M06	Clutch
N7	50BC525M07	Washer
N8	50BC525M08	Flange nut M8
N9	50BC525M09	Flywheel
N10	50BC525M10	Bolt M5x20
N11	50BC525M11	Ignition coil
N12	50BC525M12	Cap, Spark plug
N13	50BC525M13	Spark plug
N14	50BC525M14	Bolt M5x20
N15	50BC525M15	Bolt
N16	50BC525M16	Bolt M5x10
N17	50BC525M17	Bolt M4x12
N18	50BC525M18	Cover, Cylinder
N19	50BC525M19	Top cover
N20	50BC525M20	ST4x8
N21	50BC525M21	Brand badge
N22	50BC525M22	Bolt M6x55
N23	50BC525M23	Heat insulation, Muffler
N24	50BC525M24	Bolt M5x10
N25	50BC525M25	Muffler
N26	50BC525M26	Bolt M4x14
N27	50BC525M27	Gasket, Muffler
N28	50BC525M28	Cylinder
N29	50BC525M29	Gasket, cylinder
N30	50BC525M30	Piston ring
N31	50BC525M31	Piston
N32	50BC525M32	Piston pin
N33	50BC525M33	Snap ring. Piston pin
N34	50BC525M34	Needle bearing
N35	50BC525M35	Gasket, Inlet pipe
N36	50BC525M36	Inlet pipe
N37	50BC525M37	Gasket, Carburator
N38	50BC525M38	Carburator
N39	50BC525M39	Air filter set
N40	50BC525M40	Bolt M5x55
N41	50BC525M41	Element
N42	50BC525M42	Cover, filtre
N43	50BC525M43	Knob
N44	50BC525M44	Brand badge
N45	50BC525M45	Pin \varnothing 5x10
N46	50BC525M46	Oil seal 10x30x7
N47	50BC525M47	Bolt M5x35
N48	50BC525M48	Left crankcase
N49	50BC525M49	Bearing 6202

No.	ID Zboží	Název
N50	50BC525M50	Woodruff key
N51	50BC525M51	Crankshaft
N52	50BC525M52	Gasket, crankcase
N53	50BC525M53	Right crankcase
N54	50BC525M54	Oil seal 12x22x7
N55	50BC525M55	Pullet
N56	50BC525M56	Nut M8
N57	50BC525M57	Starter ass'y
N58	50BC525M58	Screw
N59	50BC525M59	Ratchet
N60	50BC525M60	Torsion spring
N61	50BC525M61	Reel
N62	50BC525M62	Spring
N63	50BC525M63	Nut
N64	50BC525M64	Starter
N65	50BC525M65	Starter rope
N66	50BC525M66	Starter knob
N67	50BC525M67	Collar
N68	50BC525M68	Fuel tank ass'y
N69	50BC525M69	Cap
N70	50BC525M70	Equilibrator
N71	50BC525M71	Clip
N72	50BC525M72	Fuel pipe
N73	50BC525M73	Pipe set
N74	50BC525M74	Fuel filter
N75	50BC525M75	Tank
N76	50BC525M76	Branket, tank